XT2USB manual Windows drivers installation

20240528

1. unzip XT2USB_drivers.zip file to any directory on your PC (e.g. C:\XT2USB)
2. open Device Manager on your PC
3. check if some device has missing drivers

4. Update drivers of that device

5. Select Browse my computer for drivers

6. Select the path of the drivers e.g. C:\XT2USB

7. Go Next

8. The following devices are supposed to be installed:

Avaya OCC Hub
Grabber
USB Audio device